


Using the Guide to Purchase PPV

- GUIDE** Display the Guide
- B** Display Themes
- Highlight theme:
Pay Per View
- Display Program list
- Highlight a PPV title
- SELECT OK** View purchase information
- B** Purchase the PPV title
- B** Accept to continue



PIN entry is required if the Purchase PIN setting is enabled

Use this button to view more information about a program



Set a Recording Timer

- GUIDE** Display the Guide and highlight your purchased PPV event
- SELECT OK** Display VCR Timer option
- A** Set VCR Timer



Using the QuickMenu™

- MENU** Display QuickMenu (if available)
- Scroll through categories of shortcuts
- Highlight a shortcut on the list
- SELECT OK** Display the selected item




Access 'Video-On-Demand' from the QuickMenu

- MENU** Display the QuickMenu
- Scroll to the VOD category
- Highlight the VOD shortcut
- SELECT OK** Display VOD Channel

Use this button (if available on your remote) to go to the VOD channel

Follow the screen prompts to select and purchase a VOD offering

Your Remote Control



Note: Your remote may appear different.

All screen designs © 2006 - 2007 Aptiv Digital, Inc.


DIGITAL CABLE PROGRAM GUIDE

Quick Tips Guide



PASSPORT®

Version 5.0



SELCO

Browsing for Shows

- Display the Channel Banner
- Browse by time (Hold to speed scroll)
- Browse by channels (Hold to speed scroll)
- Press again to display QuickInfo™ for extended program information
- Display more pages of information
- View selected program



Using the Guide

Find Shows by Time

- Display the Guide
- Browse by time
- Browse by channels
- Enter a channel number
- Scroll channels a page at a time (Hold to speed scroll)



Find Shows by Theme

- Display Theme
- Scroll a page at a time
- Highlight a desired theme
- Display Program list
- Scroll programs




Search for Shows

- Display Search
- Select highlighted Search Option
- Highlight a Letter
- Enter a letter to spell a title or keyword
- Press until the program list is active
- Scroll programs




Using the Settings Menu

- Display Quick Settings
- Display General Settings for more settings options



Setting Up Your Favorite Channel List


- Highlight Favorite Channels
- Display Channels list
- Highlight a channel
- Add or remove from the Current Favorites list



View your favorite channels by pressing the Favorite button

Set a Recording Timer


- Highlight VCR Timer
- Select a channel, day, start time and stop time
- Accept the settings



Settings Menu: Parental Control

Establish a PIN Number

- Highlight Parental Control
- Display Initial PIN Setup Follow the on screen prompts to establish your PIN



Require a PIN to Purchase Shows


Note: This option is independent of Parental Control options

- Highlight Purchase PIN
- Display the State list




(Continued)

- Highlight Enable
- Select Enable and enter your PIN
- Accept a confirmation



Activate Parental Control Settings

- Highlight Parental Control
- Display the State list
- Highlight Enable
- Select Enable and enter your PIN
- Accept a confirmation




Require a PIN to View Shows by Rating

- Highlight Blocked Ratings
- Display the Rating list
- Highlight a rating
- Lock the rating and all higher ratings



Require a PIN to View Shows by Channel

- Highlight Blocked Channels
- Display the Channel list
- Highlight a channel
- Lock or unlock the channel



Require a PIN to View Show by Time

- Highlight Blocked Time
- Display On/Off list
- Highlight On
- Select a day or days, start time, and stop time
- Accept the settings



Use the Blocked Titles option to:

- Hide NC-17 and NR(Adult) rated titles
- Require a PIN to view like rated shows